

Overdrive D Type

1) GASKET ADAPTER PLATE	106437	29) PISTON OPERATING CLUTCH (2req)	513220
2) GASKET MAIN CASING	37H1901	30) O RING PISTON OPERATING CLUTCH (2req)	506130
3) DRAIN PLUG	506114	31) SUNWHEEL CIRCLIP	506091
4) SEAL	506118	32) CIRCLIP	515356
5) FILTER COVER	506097	33) SPRING (4req)	513199
6) FILTER COVER GASKET	506098	34) CLUTCH RETAINING PLATE	506104
7) FILTER	513202	35) CLUTCH THRUST BEARING	506112
8) SEALING PLATE	506107	36) CLUTCH SLIDING MEMBER (\$90 core charge)	513200
9) RELIEF VALVE PLUG	N/A	37) SUN WHEEL	506044
10) WASHER	506118	38) RING SPRING	513223
11) O RING	506129	39) CAGE ROLLER	502559
12) PLUNGER OIL PUMP	513196	40) SPRING FOR CAGE	513208
13) SPRING	500633	41) ROLLERS	506063
14) BALL BEARING	BL0014	42) CIRCLIP SUN WHEEL	513210
15) SEALING WASHER	506118	43) RETAINING PLATE	513215
16) PLUG	513206	44) THRUST WASHER	500613
17) O/D CAM	513216	45) NEEDLE ROLLER BEARING	506113
17a) KEY	KW316	46) ANNULUS	513195
18) GASKET	513204	47) BEARING FRONT ANNULUS	506111
19) COVER	506109	48) DRIVE GEAR	506099
20) SOLENOID	512114	49) REAR BEARING ANNULUS	533360A
20a) SOLENOID GASKET	513201	50) O RING	506115
21) OPERATING VALVE LEVER	506064	51) SPEEDO DRIVE GEAR ASSEMBLY	506067
22) O RING	500594	52) SPEEDOMETER ANGLE DRIVE	120694
23) PLUNGER BALL VALVE	500591	53) OVERDRIVE SWITCH BRACKET not illustrated	133770
24) BALL BEARING	BL0020		
26) RING CLUTCH	513228		
27) REAR SEAL	513231		
28) OUTPUT FLANGE	513212		

Rebuilt Overdrive D Type

REBUILT D TYPE O/D (\$200 Core charge) 307862

