

Electrical Components

1) BATTERY CABLE NEGATIVE	515997	44) HORN HIGH NOTE	XDH112H
2) BATTERY RETAINER BAR	142087	44) HORN LOW NOTE	XDH112L
3) J BOLT, WASHER & WING NUT (2req)	613051/KIT	44) HORN HIGH NOTE LUCAS	GGE164
4) BATTERY CABLE POSITIVE	515873	44) HORN LOW NOTE LUCAS	GGE165
5) TERMINAL BOOT	115706	45) WIPER MOTOR GEAR	520101
6) BATTERY MAT (rubber)	613155	46) BOLT PLAIN WASHER & LOCK WASHER (2req)	HU704/LW
7) BOLT & SHAKEPROOF WASHER (GHF32	HU704/SW	47) WIPER MOTOR MOUNTING PAD	150844
8) BATTERY LABEL	LBL1	48) WINDSHIELD WIPER MOTOR	LRW110
9) TURN SWITCH LABEL	611011	49) WIPER MOTOR STRAP RUBBER	150845
10) TURN SIGNAL < 1976 (FM60006) LUCAS	158966	49) WIPER MOTOR STRAP WITH RUBBER	BHA4790
11) CENTER HORN PUSH UP TO 1976	159761	50) WIPER RACK	37H5208
12) BRUSH (horn push) 3.4"	108657	51) GROMMET	131155
12) BRUSH (horn push) 2.6"	142534	52) WIPER MOTOR PARK SWITCH	520160A
13) PAN HEAD SCREW & STAR WASHER (4r	TP402/SW	53) WIPER MOTOR BRUSH SET	RTC198A
14) LIGHT HIGH LOW SWITCH up to 1976	35859	54) BODY HARNESS 1500 UP TO FM10,000	159939
15) LIGHT SWITCH LABEL	621968	54) BODY HARNESS 1500 FM10,001 - FM28,000	UKC1489
16) LIGHT / DIMMER / TURN 1977- 1980	30968A	54) BODY HARNESS 1500 FM28,001 - FM40,000	UKC4220
17) WIPER SWITCH 1977 - 1980	30970	54) BODY HARNESS 1500 FM40,001- FM60,006	UKC7065
18) IGNITION SWITCH 1971 - 1973	39415	54) BODY HARNESS 1500 FM60,006 onwards	UKC8212
18) IGNITION SWITCH 1974 - 1976	30563	55) GROMMET	600400W
18) IGNITION SWITCH REPRO 1974 - 1976	30563X	56) MAIN & BODY HARNESS MK4 FK1 - FK30,441	313273
18) IGNITION SWITCH 1977 onward	30981A	56) MAIN HARNESS MK4 from FK30,442	RKC570
19) STEERING LOCK 1971 - 1976	UKC2719	56) MAIN HARNESS 1500 UP TO FM10,000	313268
19) STEERING LOCK (New Old Stock) 1971 -	UKC2719nos	56) MAIN HARNESS 1500 FM10,001 - FM28,000	RKC959
19) STEERING LOCK 1977 - 1980	RKC3983	56) MAIN HARNESS 1500 FM28,000 - FM40,001	RKC926
20) COURTESY LIGHT SWITCH 1971 - 1973	627733	56) MAIN HARNESS 1500 FM40,001 - FM60,006	RKC2873
20) COURTESY LIGHT SWITCH 1974 - 1980	YKC931	56) MAIN HARNESS 1500 FM60,006 - FM95,001	RKC3195
21) SELF TAPPING SCREW	YZ3304	56) MAIN HARNESS 1500 FM95,001- FM110,001 FEL	PKC767
22) FUSE BOX WITH COVER	521030	56) MAIN HARNESS 1500 from FM95,001 CA	PKC766
23) FUSE 35AMP (3req)	GFS35	56) MAIN HARNESS 1500 from FM110,001 FED	PKC766
24) FUSE BOX COVER	607201	57) GROMMET	BW503
25) ALTERNATOR BRUSH SET	GGB504	58) GEARBOX HARNESS O/D D TYPE	155985
26) ALTERNATOR RECTIFIER	AEU4152	58) GEARBOX HARNESS O/D 1974 J TYPE	159653
27) ALTERNATOR BOLT, WASHER & NUT	HB839/WN	58) GEARBOX HARNESS O/D 1975 - 1980	UKC4612
28) ALTERNATOR SPACER	147483	58) GEARBOX HARNESS NON O/D 1971-1974	158371
29) BOLT & LOCK WASHER (2req)	HU808/LW	58) GEARBOX HARNESS NON O/D 1975-1980	UKC4481
30) MOUNTING BRACKET USED	147899USED	59) OVERDRIVE SHIFT LEVER HARNESS	153726
31) PULLEY	AEU1238	60) STD ALTERNATOR PLUG KIT	CYB400
32) BOLT, WASHERS & NUT	HU858/WN	61) SINGLE BULLET CONNECTING SLEEVE	BW311
33) ADJUSTING LINK	156464	61) DOUBLE BULLET CONNECTING SLEEVE	BW312
34) FAN BLADE	AAU3956	61) TRIPLE BULLET CONNECTING SLEEVE	BW323
35) ALTERNATOR REBUILT 16 ACR	GEU207	61) BULLET CONNECTORS	BW309
35) ALTERNATOR NEW 18 ACR	LRA100	62) STARTER SOLENOID	RTC461R
36) STARTER MOTOR BRUSH SET (M35G)	GSB102		
37) DRIVE GEAR 9 TOOTH	67H5010		
38) SPRING	7H5045		
39) SHIM	104549		
40) MOUNTING BOLT, WASHER & NUT	HB917/WN		
41) STARTER MOTOR ASSEMBLY	LRS101N		
42) STARTER MOTOR TO SOLENOID CABLE	UKC1363		
43) BOLT, WASHERS & NUT	HU705/WN		

Other Wiring Components

HEADLAMP HARNESS (2req) not illustrated	BAU2110
EARTH LEAD RACK TO ENGINE not illustrated	134301

Electrical Components

